

ENERGY DISPENSER ASSEMBLY GUIDE

1




Colored side



Greyscale side




A




B

1st - Fold



2nd



2




C





D

1st




2nd



3



E




4



1st - Fold




2nd






3rd




F







1st - Fold



2nd



WHEN PUTTING IT AWAY

